



Threadless Injection Fitting



Blue-White
Industries, Ltd.

5300 Business Drive
Huntington Beach, CA 92649
714-893-8529 www.Blue-White.com


Threadless Injection Fitting



Blue-White
Industries, Ltd.

5300 Business Drive
Huntington Beach, CA 92649
714-893-8529 www.Blue-White.com


Threadless Injection Fitting



Blue-White
Industries, Ltd.

5300 Business Drive
Huntington Beach, CA 92649
714-893-8529 www.Blue-White.com

Threadless Injection Fitting



Blue-White
Industries, Ltd.

5300 Business Drive
Huntington Beach, CA 92649
714-893-8529 www.Blue-White.com

Installation Instructions Threadless Injection (T.I.) Fitting

1. Drill a 3/8" diameter hole in the pipe to be treated.
2. Place the O-ring seal on the pipe, around the opening, and insert the T.I. fitting. Make certain the fitting is place in the correct position, downstream from the flow.
3. Secure the T.I. fitting to the pipe using the mounting clamp provided.
4. Attach the pump discharge tubing to the intake point on the T.I. fitting, and secure with the tube nut.

Rev. 1/04

80000-053

Installation Instructions Threadless Injection (T.I.) Fitting

1. Drill a 3/8" diameter hole in the pipe to be treated.
2. Place the O-ring seal on the pipe, around the opening, and insert the T.I. fitting. Make certain the fitting is place in the correct position, downstream from the flow.
3. Secure the T.I. fitting to the pipe using the mounting clamp provided.
4. Attach the pump discharge tubing to the intake point on the T.I. fitting, and secure with the tube nut.

Rev. 1/04

80000-053

Installation Instructions Threadless Injection (T.I.) Fitting

1. Drill a 3/8" diameter hole in the pipe to be treated.
2. Place the O-ring seal on the pipe, around the opening, and insert the T.I. fitting. Make certain the fitting is place in the correct position, downstream from the flow.
3. Secure the T.I. fitting to the pipe using the mounting clamp provided.
4. Attach the pump discharge tubing to the intake point on the T.I. fitting, and secure with the tube nut.

Rev. 1/04

80000-053

Installation Instructions Threadless Injection (T.I.) Fitting

1. Drill a 3/8" diameter hole in the pipe to be treated.
2. Place the O-ring seal on the pipe, around the opening, and insert the T.I. fitting. Make certain the fitting is place in the correct position, downstream from the flow.
3. Secure the T.I. fitting to the pipe using the mounting clamp provided.
4. Attach the pump discharge tubing to the intake point on the T.I. fitting, and secure with the tube nut.

Rev. 1/04

80000-053